

TECH BULLETIN

TEK-B15

Ford Mustang Hydraulic Shim

Application...2005-10 4.6 Ford Mustang

Clutch Kit.....07-187

Subject.....Installing Hydraulic Shim

To install the shim, you must remove the hydraulic release bearing by removing the two 10mm bolts and plastic fastener clip that holds the hydraulic line connector inside the transmission bell housing. Place the shim behind the release bearing and replace bearing. Torque the two 10mm bolts to 8ft.-lbs.

Caution: *You must vacuum bleed the hydraulic system for proper operation. Refer to original equipment manual for detailed procedure.*

